

INTELLIGENT FILM HANDLING GUIDELINES



IMPORTANT INFORMATION

1. Never fold, bend or curve the film. Always keep the film flat and straight as highlighted in picture 1.
2. Do not remove the protective liners until you are ready to install the film.
3. When handling the film always wear nitrile gloves.
4. When handling the film always be careful with the edges to avoid delamination.
5. Always ensure that the bus-bar (electrical contact strip) is covered / protected.
6. If cutting the film, use either scissors or a sharp blade to avoid delamination on the edges.
7. Never use any chemicals or abrasive cleaners on the film surface. We recommend either IPA or a mild liquid glass polish and a soft lint-free cloth.

Pro Display Intelligent Film must always be powered using 110VAC.